## **TECHNICAL DATA SHEET**



# **Promo Ceiling**

**Description:** Wall paint with good hiding capacity for finishing walls and ceilings in dry rooms, for interior use.

**Application:** Suitable substrates are: cement and plasterwork, concrete, brickwork, plasterboard, board, wallpaper, etc. Also suitable for painting glass fibre fabric.

#### Properties:

- Solvent-free and virtually odourless
- Good hiding capacity
- Breathable
- Easy to wash
- Mat
- Water-soluble

Colours: White

**Handling:** Stir thoroughly prior to use. Apply in 1 or 2 coats with a square pasting brush, woolly roller or airless spray. Dilute the first layer with no more than 10% of water as required. Apply the second layer undiluted.

**Covers:** According to ISO-6504-3 and DIN EN 13300 approx. 7 m²/litre per coat, depending on the surface. Deposition efficiency: class 3

**Drying time at 23°C and relative humidity of 65%:** Dust-dry after approx. 2 hours.

Can be painted over after approx. 4-6 hours.

#### SYSTEM CONSTRUCTION

**Substrate:** The surface must be clean, dry and free from dust or grease. Sand and repair surface irregularities. Remove and/or repair all loose and unstable coats.

**New plasterwork:** Prime with Finess Wall Paint Primer or Finess Transparent.

**Existing plasterwork:** Clean using water and a degreasing agent. Allow to dry. Prime with Finess Wall paint Primer.

**Powdery substrates:** Clean thoroughly with clean water and allow to dry. Prime with Finess Stabilising Primer.

Non water-resistant (rub-resistant) coats of paint: Wash thoroughly until the surface does not flake or dust anymore. Next, prime with Finess Stabilising Primer.

**Concrete:** Remove any 'cement skin' and dust thoroughly using a brush. Next prime the surface with Finess Wall Paint Primer.

**Aerated (cellular) concrete blocks:** Prime using a special priming agent. Next, apply a coat of plaster. After drying, prime the surface with Finess Wall Paint Primer.

**Plasterboard:** Bridge the joints with plaster mesh tape and fill with a suitable filler. After allowing to dry: Next prime the surface with Finess Wall Paint Primer..

**MDF, chipboard and fibreboard:** Sand smooth boards, remove any dust and seal the surface using Finess Sealing Primer.

**Load-bearing coats of paint:** Clean using water and a degreasing agent. First, sand down glossy coats of paint until matt and carefully ensure the substrate is free of dust.

Substrates stained by nicotine, damp, rust or soot: Wash with water and a degreasing agent and allow to dry well. Next, seal the surface of the substrate with Finess Sealing Primer.

#### **TECHNICAL DATA**

Binding agent: Solvent-free synthetic resin dispersion

Pigments: Rutile titanium dioxide and mineral

fillers

Solvent: Water

Solid

components: 62% by weight

SG: Approx. 1.5 g/ml

Viscosity: Viscolab LC 3: 5.5 PaS @ 20°C

Fineness: 50 microns ISO-787-7 and DIN EN

13300: fine

Degree of gloss: Matt ISO-2813 and DIN EN 13300:

60°/2.3% 85°/5%

Tint: White

Dilute with: Water

Hazard classification:

See safety information sheet (MSDS)

**Tool cleaning** 

**instructions:** Use water and soap.

**Features:** Washability according to DIN 53778:

>5000 cycles Class: S

Scrub resistance according to ISO-11998 and DIN EN 13300: class 2

#### Storage:

Minimum of 12 months in the tightly sealed original packaging in a dry, cool and frost-free place.

#### General:

Stir thoroughly prior to use. Do not apply in temperatures below +8°C, in direct sunlight or when rain is expected. Allow newly cemented surfaces to set for at least 6 weeks.

### Surplus product:

This paint and the packaging should be disposed of at a collection point for hazardous or special waste.